

Overview

The Marvell Ethernet SLD contains a component that supports the Marvell 1GB Ethernet controller chip. The component supports driver version 6.28.0.0. Only the SLD is supplied in the ZIP file. You will need to run the installation utility to extract the driver files. Here is the list of files:

gewmi.mof
mrvdlg.dll
oem1.inf (You will have to look inside the INF to be sure it is for the Marvell Yukon driver)
yukonwpx.sys

Instructions:

1. **Install** the Ethernet driver on an XP Pro system to capture the files listed above.
2. **Download** the ZIP file containing the SLD.
3. **Extract** the contents of ZIP file to your hard drive.
4. Create a new directory in the same directory as the SLD called **Files**.
5. **Copy** the extracted driver files listed above to the **Files** directory. The Repository path is relative to the SLD. The Repository has been setup so the files are one directory level below the SLD.
6. **Import** the SLD into the XPe data base using Component Database Manager.

For any questions, please contact us at www.sjjmicro.com / support@sjjmicro.com.